

MAINTENANCE

Cleaning the secondary filter

At the end of the irrigation season and during the irrigation season, at the frequency required by the irrigation water quality.

Remove the filtration element from the filter casing and clean it according to the instructions in the filter user manual.