

MAINTENANCE

Paint retouching of the tanks and manifolds



WARNING

If the protective coating (inside and outside) of the tanks and manifolds is damaged and the bare metal is exposed, it will rust in contact with irrigation water and chemicals. If neglected, this will lead to a leak.

A tin of polyester protective repair paint (color: RAL 5010) is supplied with the system.

Any damage to the protective coating of the tanks and manifolds must be repaired as soon as possible.

1. Sand the damaged area or spot with sandpaper and clean it with a wire brush.
2. Apply the protective paint.
3. Let the paint completely dry for at least 24 hours before exposing the mended spot to water.

For further assistance, contact your local Netafim™ representative.